

PAINT INDUSTRIES PTY LTD

A.C.N. 008 753 839

TELEPHONE

(08) 9437 1488

FAX: (08) 9410 2395

61 Lionel Street
Naval Base 6165
WESTERN AUSTRALIA

P.O. BOX 83
North Fremantle 6159
WESTERN AUSTRALIA

MADE IN WA
GUARANTEED QUALITY
DATE: 31/01/2009

PRODUCT BULLETIN

T.F. 402

MASTERPIECE CLEAR TIMBER FINISH

GLOSS	7004
SATIN	7030
MATT	7003

Description: A superb one pack clear polyurethane finish for all timber & cork surfaces, available in gloss, satin & matt finish. The excellent film clarity highlights & enhances timber grain & colour.

Properties: Extremely tough & durable. Resistant to scuff marks, scratches & general abrasion. Not affected by most food & household chemicals & detergents.

Uses: Ideally for use on all timber panelling, table & bench tops, furniture, skirtings, doors, plywood, hardwood & veneer. Masterpiece Gloss & Satin may be used in sheltered exterior applications, but Matt is for interior use only. Can be used on cork surfaces, but as some corks are not compatible, a test should be made first.

Surface Preparation: All surfaces should be free from loose dirt, grime, mould & grease.

Previously Painted Surfaces: Strip all paint by mechanically sanding or with Paint Stripper used in accordance with directions. Thoroughly sandpaper the surfaces finishing with fine paper. Proceed as for new timber.

Previously Varnished Surfaces: Thoroughly wash with mineral turps to remove all contaminants. If previous clear coating is badly perished, peeling or cracking, strip back to bare timber.

Sound surfaces must be sand papered to roughen the surface and provide a key. Dust off. Fill nail holes & surface imperfections with matching wood putty, allow to dry & sand smooth with fine paper. Dust off. If touch up or re-staining is required apply appropriate stain at this stage.

New Timber: Thoroughly sandpaper entire surface to be coated. Dust off. Fill nail holes & imperfections with matching wood putty and allow to dry. Sand smooth with fine sandpaper and dust off. If staining is required apply appropriate product and colours according to directions.

Thinning: Not usually required for normal brush application. On some open grained timber a sealer coat of Masterpiece thinned with 10% mineral turps may be used. For conventional or airless spray thin up to 10% with mineral turps.

Application: Brush or spray. On open grained timber apply first coat of Masterpiece thinned with 10% mineral turps. On dense timber apply first coat direct from can. Allow to dry. Using very fine sandpaper (400 plus) lightly sand with the grain to remove raised wood grain. Thoroughly remove all dust. For best results apply 2 or 3 further coats direct from can allowing 8 – 12 hours and lightly sanding between coats. On hard wearing surfaces the third coat is strongly recommended.

Spread Rate: Approximately 16 – 20m² per litre.

Drying Time: At 25°C, touch dry in 1 – 3 hours. Recoat after 12 hours or when each coat is able to be sanded without clogging the sandpaper. In cold or damp conditions allow longer times. Do not use when temperature is, or may fall below 10°C.

N.B. Full resistance and total cure of the film takes several days and it is recommended that the surface film should not be exposed to heavy wear, hot dishes etc for at least 5 days.

Clean-Up: Clean all equipment immediately after use with mineral turps.

Standard Packaging: 4L 1L 500 ml.

Colour: Clear only.

This information is drawn from data which at the time of printing is believed by Paint Industries Pty Ltd to be accurate. Information is provided in good faith and as a general guide to users of the product. All persons using the product should enquire independently as to the suitability of the product for the end use and the application requirements for such use. Paint Industries Pty Ltd has no control over conditions under which products are stored handled or used and any recommendations cannot be regarded as a legal warranty or liability.